

**T 35120L**


RO



# Manual de operare si intretinere

seria de fabricatie: .....

an de fabricatie: .....



4900056-RO (01-06)



BOBCAT EUROPE

---

## CUPRINS

INTRODUCERE

INSTRUCTIUNI DE SIGURANTA

MOD IDENTIFICARE

SPECIFICATII TEHNICE

CABINA OPERATOR

SISTEM CONTROL SARCINA

VEDERE GENERALA

CUTIE SIGURANTE

LUBRIFIERE

PRIMA LUCRARE DE INTRETINERE

INSPECTII PERIODICE

ALIMENTARE COMBUSTIBIL

INTRETINERE BATERIE

TRANSPORT