

TD 40105


RO



Manual de operare si intretinere

seria de fabricatie:

an de fabricatie:



4850600-RO



BOBCAT EUROPE

CUPRINS

INTRODUCERE

INSTRUCTIUNI DE SIGURANTA

MOD IDENTIFICARE

SPECIFICATII TEHNICE

CABINA OPERATOR

SISTEM CONTROL SARCINA

VEDERE GENERALA

CUTIE SIGURANTE

LUBRIFIERE

PRIMA LUCRARE DE INTRETINERE

INSPECTII PERIODICE

ALIMENTARE COMBUSTIBIL

INTRETINERE BATERIE

TRANSPORT